

## Attention Read First before use

If the date and time are incorrect on your DigaPEN Go to: [http://www.diganet.net/htm\\_docs/firmware\\_downloads.htm](http://www.diganet.net/htm_docs/firmware_downloads.htm) and download the the update.

## Introduction

Thank you for purchasing your DigaNET personal digital video/audio recorder. Ideal for situations that require video/audio proof. The DigaPEN is small enough to conceal almost anywhere! Wherever you place your DigaPEN, you'll know for sure that we will give you **Digital Video/Audio Evidence When You Need It!**



1. Camera

2. MIC


3. USB



4. Record And Power Light

5. Power on/off

6. Reset



What your DigaPEN includes:  
DigaPEN video/audio AVI recorder  
USB cable

## DigaPEN Specifications

Video compression : AVI video format; 640x480

Voice recording: Yes

Internal memory: Yes

Flash: 2GB, 4GB or 8GB

Video file size: 500KB per min

Recording mode: Continuous recording or manually recording

Adaptor type: USB adaptor charging cable

Battery type : Lithium-ion

Record time : up to 1-1.5 hours

## Features

Dimensions: 5.9"X.6"X.6"

Weight: 1.06 oz.

Tiny size makes it ideal for a variety of uses.

Plug n' Play capability, no drivers needed for XP or Windows 2000

Real time recording in AVI video format

Internal memory: 2GB, 4GB or 8GB

## Starting your DigaPEN Video/Audio Recorder

Step 1: Press the power button and the yellow light will come on as it warming up; the DigaPEN begins to record video/audio as soon as the yellow light changes to blue. The blue light will stay on during video/audio recording.

Step 2: Press the power button again; it will save the data and turn off.

Step 3: To start a recording again, follow Step 1.

Step 4: Hold down the switch for 5s, then the power switch is off, after shutting down the DigaPEN, there is no light.

Step 5: When finished charging the battery, the light stops flashing and the yellow light stays on in sleep mode, this means that battery is fully charged (We suggest you hold the button down till the yellow light shuts off to conserve the battery).

Step 7: The DigaPEN will turn itself off when the battery has been depleted. The video/audio recording files will be saved before shutting down.

## Brief introduction

1. The first mini DVAR in the world which is concealed in a pen. And the first pen with the functionality of both video/audio recording.
2. The high fidelity microphone can record the sound around 30' High resolution video will capture any event with clarity.
3. The DigaPEN is a functional writing instrument.
4. Pinhole camera lens.

## Connect to PC with USB cable

1. Connect the DigaPEN to the computer with USB cable. The DigaPEN is in the state of charging while the yellow light is on. Charge at least 2 hours before first use.
2. Functions as removable disk when you connect the DigaPEN to PC. Playback the video files stored in flash via the computer. Download the free software at [www.diganet.net](http://www.diganet.net)
3. Make sure you charge the DigaPEN at least 2 hours.

## FAQ

Q: Can the video file which is recording be stored if the battery goes out during download or viewing?

A: Yes. Simply charge the battery and once charged you will be able to view or download the video files.

Q: What if the DigaPEN locks up?

A: Simply press the "RESET" button with a small object, then push the on/off switch and the DigaPEN will operate.

Q: What type of format do I use?

A: Use "FAT32" to format the flash drive.